



# GROWALL Raised Garden Bed Kit



## INSTALLATION GUIDE

### Thank you for purchasing your GroWall Raised Garden Bed Kit by Envirolok!

You are on your way to creating a living landscape feature to fit your style. **If you have any questions before, during, or after your installation, simply email [ecosolutions@envirolok.com](mailto:ecosolutions@envirolok.com) or reach us at [growall-systems.com](http://growall-systems.com).** We expect your journey to be fun and rewarding! We can't wait to see your before and after photos!



Go to [growall-system.com/installation](http://growall-system.com/installation) or scan here for more detailed instructions and step-by-step installation videos.

## What you need to get started

### Tools:

- tape measure
- shovel
- hand tamper
- hard rake
- level
- safety glasses
- 5 gal. bucket
- 8" concrete form tube
- utility knife
- bag fill

### Plants:

Select your vegetation and have it ready to go during installation. If you still need to purchase plants or seed, we've included a discount coupon for Agrecol Native Plant Nursery!

## Included in your Kit



### Growall Units

- Each Unit Includes: 1 Bag, 1 Closure Tie

## step 1 Fill Bags

Bag fill should be a mix of 60-80% Sand / 20-40% Topsoil. In some cases, on-site material may be used if it is free of heavy clay.

- .7-.8 cubic feet / bag
- 55-70 lb carrying weight

Filled & compacted dimensions:

- +-26" L x 10.5" W x 5" H



scan here for complete filling instructions

## step 2 Dig the Trench



Mark off the face edge of your raised garden bed. Dig a 1"-2" deep trench along the perimeter of the garden bed. The trench should be a minimum of 12" wide from the face edge of the raised garden bed.

## step 3 Place Pins & Bags



Place the pins along the trench, spacing them 12-18" apart. Next, place the first course of bags over the pins, so two pins connect with each bag. It's okay if you need to move pin locations as you go. Be sure the bags fit tightly to one another and the "snorkel" is tucked below the bag.



## INSTALLATION GUIDE

### step 4 Compact Bags



Once the row is in place, use a hand tamper to level and compact the bags. For beds taller than 24" high, we recommend compacting each bag after it is set, as it is easier to level.

### step 5 Backfill



Fill the space behind the bags with backfill material and rake level so that the material is 2"-3" higher than the bags. Next, compact the backfill material with a hand tamper until the level is even with the top of the bags.

### step 6 Add Plants



Next, place plant material (2 plants per bag) on top of the bags, so the root crown or top of soil will be even with the bag above. Place a handful of soil around the plant roots. Adjust plants as needed as you install the course above.

### step 7 Additional Courses



Repeat steps 3-6 until you reach your desired bed height. Be sure to set the bags in a brick pattern, so that the bag above spans the seam between two bags below by at least 8". Backfill behind each course once completed. Level each bag as needed by adjusting the snorkel wrap length.

#### IMPORTANT:

1. Determine your bag setback to match the existing or desired slope. A maximum of 6" setback is recommended between courses.
2. If vegetating with seed or sod, go to [growall-system.com/installation](http://growall-system.com/installation) for full details.

### step 8 Complete



Once you have completed your raised bed, cover the top course of bags with 1-2" of soil or mulch prior to planting.